

Instructions for B's FAB - Polaris Xpedition Antenna / Whip Mounts

The bracket mounts using the existing factory roll cage bolt, but you must gain access to the nut on the inside of the machine by removing the upper interior plastic panel, see instructions below

1. If your machine has rear speakers you will need to remove them by removing two T-40 torx head screws and one electrical plug.
2. To remove the upper interior plastic panel, you will need a T-40, T-27 and a push pin removal tool. See diagram below for fastener locations and types. The seat belt mount **DOES NOT** need to be removed to remove the plastic panel.



3. Remove the roll cage bolt using an 18MM socket, reach around to the inside of the machine and hold the nut with your fingers so it doesn't drop into the abyss, never to be seen again, no wrench is needed as it has stops so it won't spin but it WILL fall.
4. Slide your new antenna / whip mounting bracket onto the factory roll cage bolt and Reinstall reusing the factory nut. Torque bolt to factory specifications (1 Ft. Lb.)
5. Reinstall the upper interior plastic panel
6. Install the supplied cap into the antenna / whip mounting bracket, using a rubber or plastic mallet works well
7. DONE!

Thank you for your order!

We greatly appreciate your business. Your satisfaction is very important to us. If for any reason you are not satisfied, please contact us so that we can resolve any issues that you may have.

We have taken great care to manufacture, pack and ship your order as quickly and professionally as possible. When you are happy with your order, please let others know by leaving us a 5 star rating on our website, positive feedback on eBay, commenting on our Facebook page or posting on the Polaris General forum and Facebook groups. This lets us know that you, our valued customers are happy with our product and services and this also helps others in making the right decisions on whom to buy from.

Web – www.bsfabutv.com

Email – info@bsfabutv.com

Phone – 888-779-1497